

# 3rd party app - What to do if a 3rd party app is displayed in portrait mode?

When you use 3rd party apps on 2N® Indoor Touch, some of them may display their interface in portrait mode, even if they need for proper function to be displayed in landscape mode.

You can easily setup 2N® Indoor Touch to force apps to use Landscape mode.

## How to force application to use landscape mode?

1. Open settings on 2N® Indoor Touch
2. Navigate to Software section
3. Enable Force applications to landscape orientation

Now all 3rd party apps will successfully run in landscape mode.