



## How many system (key) phones can be used?

You can use up to 10 system (key) phone modules, i.e. up to 20 system (key) phones in OmegaLite/Omega48. The maximum of 460 keys could be supported.

More product information:  
[Private Branch Exchanges \(Official Website 2N\)](#)