

Connection via HyperTerminal - How can I connect using HyperTerminal?

HyperTerminal is a program included in Windows. You can find it in menu Start > All programs > Accessories > Communication.

For connection to the gateway using COM port you should set following parameters:

1. Btrate set to 57600
2. Flow control set to none
3. Rest of values will stay default

Second option is to use TCP/IP connection. When you use TCP/IP, you have to use port 23 for the communication with the gateway.

More product information:

[2N® StarGate VoIP \(Official Website 2N\)](#)

[2N® BlueTower VoIP \(Official Website 2N\)](#)