


# Password issue with 2N® IP Intercom - My old admin password does not work

From firmware version 2.17 it is mandatory to change the password upon the first login, you will be asked by a dialog window to change the password . Default credentials are:

username: Admin

password: 2n

## How to change password - 2N® IP Intercom



The screenshot shows the web interface for a 2N IP Vario device. The top navigation bar includes the device name '2N IP Vario', language options 'CZ | EN | DE | FR | IT | ES | RU', and a 'Logout' link. The main content area is divided into sections: 'Basic Settings >', 'Advanced Settings >', and 'User Localization >'. Under 'Basic Settings', there are three fields: 'Device Name' (2N IP Vario), 'Web Interface Language' (English), and 'Password' (masked with dots). A red box highlights the 'Password' field and its edit icon. On the left, a 'Services' menu is visible, with 'Web Server' highlighted by a red box.

More product information:  
Door & Security Intercoms (Official Website 2N)