

Server logs - 2N® SmartCom server

All logs from server are available through http protocol. HTTP port can be set in the course of 2N® SmartCom server installation (Fig. 1):




Figure 1. 2N® SmartCom setup

The second way how to find out http port is to run 2N® SmartCom license tool (Fig. 2):




Figure 2. 2N®SmartCom license tool

The third way is available in 2N®SmartCom server. Click on „Server Settings“ (Fig. 3) and in the settings you can find all installed ports (Fig. 4):




Figure 3. 2N®SmartCom server




Figure 4. 2N® SmartCom server settings

Afterwards run web browser and put IP address and http port of the server into the search field (Fig. 5):




Figure 5. Server logs

The second way how to get the server logs is from the directory (with admin rights) C:\Users\All Users\2N TELEKOMUNIKACE\2N SmartCOM\SC Server\logs

More product information:

2N® SmartCom (Official Website 2N)

2N® SmartCom PRO (Official Website 2N)